

APPLY 3/4" PLYWOOD REINFORCEMENT TO ONE SIDE OF TRUSS. ATTACH TO TOP AND BOTTOM CHORD WITH 8d NAILS AT 6" O.C.

USE A RIM BOARD

48" MAX. CANTILEVER (UNIFORM LOADS ONLY)

1-1/2 TIMES CANTILEVER LENGTH

2x_ NAILED TO ONE SIDE OF THE SPACEJOIST TE. NAIL 2x_ TO THE TE USING TWO ROWS OF 10d NAILS AT 6" O.C.

DETAIL G-2 — DROP BALCONY WITH CANTILEVER